

Assemble in 4 Easy Steps




Questions? Problems?
For Customer Support,
E-mail: service@zumbalancebike.com

STEP 1 ATTACH FRONT WHEEL

Tools required:

- 14mm wrench provided

1. Remove plastic axle protector, nuts and wheel retainers from axle. Discard axle protector.
2. Slide wheel axle into open ends of fork as shown
3. Slip a retainer onto each end of axle and hook the retainers into holes in fork end as shown
4. Install an axle nut loosely onto each end of axle
5. Center wheel in fork and tighten axle nuts securely, alternating from one nut to the other




STEP 3 ATTACH SEAT

Tools required:

- 14mm wrench provided

1. Insert seat post into frame and thread nut on seat clamp loosely
2. Position seat directly in line with top tube as pictured at left and tighten seat post clamp bolt securely




STEP 2 ATTACH HANDLEBAR

Tools required:

- 12mm wrench provided

1. Insert stem into head tube at least to minimum insertion line indicated on stem
2. Face stem forward directly in line with front wheel and tighten stem bolt securely



STEP 4 INFLATE TIRES

1. Schrader Valves—inflate with Schrader Valve Pump.

Caution: Do not over-inflate. Pressure should not exceed the recommendation indicated on tire sidewall.